Polaritet Global Trac Pro Röd linje anger polaritet XTS 35-1 XTS 35-1 XTS 34-1 XTS 34-1 XTS 35-2 XTS 35-2 XTS 34-2 XTS 34-2 XTS 35-3 XTS 35-3 XTS 34-3 XTS 34-3 XTS 39-1 XTS 38-1 XTS 40-1 XTS 38-1 XTS 39-2 XTS 38-2 XTS 40-2 XTS 38-2 XTS 39-3 XTS 38-3 XTS 40-3 XTS 38-3 XTS 35-1 XTS 35-2 XTS 35-3 XTS 37-1 XTS 36-1 XTS 37-2 XTS 36-2 XTS 37-3 XTS 36-3 XTS 12-1 XTS 11-1 XTS 41-1 XTS 12-2 XTS 11-2 XTS 41-2 XTS 12-3 XTS 11-3 XTS 41-3 XTS 41-1 XTS 41-2 XTS 41-3